

COFFEE MACHINE CLEANER & DESCALER Cleans and descales all types of coffee machines, as well as kitchen applicances such as tea urns, dish and glass washers.





KR7 COFFEE MACHINE CLEANER & DESCALER liquid formula is ideal for all types of coffee machines, it's wide range of applications and ease of use makes it the perfect choice for professional catering.

ADVANTAGES

Cleans and removes coffee residue.

Liquid provides counter top convenience.

Ingredients are phosphate free.

Use on glass bowls, airpots, satellite brewers and thermal servers.

TYPICAL APPLICATIONS

Use on glass bowls, airpots, satellite brewers and thermal servers.

GENERAL INFORMATION

To scale prevent build up, descale every 6-8 weeks. After descaling, the surface scale revealed may be eroded. This is caused by normal wear and tear and in particular, the prolonged effect of the limescale, not the action of the descaler. Test a small area, where possible, before use. Heavily scaled items may require a repeat application.

APPLICATION INSTRUCTIONS

Filter machines and percolators

- Pour 100ml into reservoir and add 500ml of cold water. 1.
- 2. Switch on machine for 1 minute, then switch off and leave overnight.
- Boil the rest of the liquid through, then boil twice with 3. fresh water before use.



Setting the Standard in Cleaning & Maintenance



Cleans and descales all types of coffee machines, as well as kitchen

applicances such as tea urns, dish and glass washers.



TECHNICAL DATA

APPEARANCE PACK SIZE

Liquid 1 litre

PRECAUTIONS

Avoid spilling, skin and eye contact.

STORAGE PRECAUTIONS

Store in original container at temperatures between 4 and 40°C.

HEALTH AND SAFETY

Health and Safety Data sheet available separately.

RELATED PRODUCTS



arrowchem.com